

## **Gebrauchs- und Pflegeanleitung Touchball**

**Herzlichen Glückwunsch zum Kauf Ihres neuen Touchballs.**

Mit einem TOGU® Produkt haben Sie sich für ein Markenprodukt „made in Germany“ entschieden.

Als Sportgerät ist es entsprechend den geltenden EU Regelungen produziert, es enthält keine Schwermetalle und besteht aus 100% recyclingfähigem Kunststoff.

Der Touchball ist luftgefüllt und für die Selbstmassage, zur Entspannung und Regeneration. Der Touchball ist aus hochwertigem Roton (luftgefüllt) und mit einem Nadelventil versehen.

### **Pumpen:**

Zum Nachpumpen bzw. Entlüften des Touchballs verwenden Sie bitte die Original TOGU Ballpumpe für Nadelventile (Art.nr. 904400), auch erhältlich im Handel.



**Wichtig: Die Nadel immer leicht anfeuchten.  
Dann gerade und vorsichtig in das Ventil einführen.**

### **Temperatur-Beständigkeit:**

Das Gerät soll idealerweise bei Raumtemperatur eingesetzt werden.

### **Pflege:**

Zum Reinigen des luftgefüllten Touchballs können Sie alle milden, handelsüblichen Reinigungs- sowie Desinfektionsmittel verwenden. Lösungsmittelhaltige, säurehaltige oder ätzende Reiniger greifen das Material an.

## **Instructions for use and care of the Touchball.**

### **Congratulations on the purchase of your new Touchball.**

With a TOGU® product you have decided for a brand product "made in Germany". As a sports equipment it is produced according to the valid EU regulations, it does not contain any heavy metals and consists of 100% recyclable plastic.

The Touchball is air-filled and is used for self-massage, relaxation and regeneration. The Touchball is made of high quality Ruton (air-filled) and is equipped with a needle valve.

### **Inflate and deflate:**

To de- or inflate the Touchball please use the original TOGU ball pump for need valves (Art.nr. 904400).



**Important: Moisten the needle and insert the needle straight and carefully into the valve.**

### **Thermal stability:**

The Touchball is UV-resistant and also heat-resistant to a limited degree. It can easily withstand temperatures of up to 45°C. However, the Touchball should be kept out of direct sunlight (e.g. do not store on window-sill). The material softens as it gets warmer.

The Touchball is also resistant to cold, but should nevertheless not be stored at temperatures below -10°C. The material hardens as it gets colder.

### **Care:**

Any mild standard cleaning agents and disinfectants can be used to clean the Touchball. Solvent-based, acidic or caustic cleaners will damage the material. The Touchball is waterproof.